


ENERGY DESK **ASSEMBLY GUIDE**





Tools Required



Battery Drill



#2 Phillips Driver Tip



#2 Square Driver Tip










Soft Hammer

Accent
workspace furniture solutions

STRAIGHT DESK


PARTS LIST

NO.	NAME	QUANTITY	IMAGE
1	Foot	2pcs	
2	Leg Top Plate	2pcs	
3	Leg Column LH/RH	2pcs	
4	Extendable Beam	1pc	
5	Bolt A	12pcs	
6	Bolt B	20pcs	
7	Desk Top	1pc	

STRAIGHT DESK


ASSEMBLY INSTRUCTION

STEP 1




Attach Leg column to Foot, using bolt A. Make sure the bolt holes on the leg column are to the back of the foot as per above.

STEP 2




Attach the extendable beam to the leg column as per above, the open side of the beam should face the back.

STEP 3




Attach the top plates to the leg columns using bolt A.

STEP 4




Place the desk top on the base frame, and extend the frame out so that holes on the top plate match the predrilled holes on the underside of the desk top. Attach the desk top to the frame with bolt B.

STEP 5



Install 2x bolt A to the front and back of the beam.

STEP 6



Energy 180 Degree Straight

