



User Guide - Smartstore G3 Planter

The following guide shows the steps for using your planter for the first time.

GETTING STARTED

1. Remove packaging

- Planters consist of smooth scratch resistant powdercoat exterior with either a perforated or plain design. Inside planter is an ABS waterproof liner and a powdercoated top tray, with holes for the plants, designed to hold bark and pebbles.

2. Prepare for use

- Remove any tape that has been used to secure planter, liner and top tray during transit.
- Before loading plants into the planter, ensure the black ABS liner is placed inside with the top tray sitting flat on the liner.

3. Loading and unloading

- Planters are designed to accommodate 20cm diameter plastic pot plants (900w hold 3 pots, 1200w hold 4 pots).
- The top tray has preset holes for even plant placement. Tabs/lugs in the preset holes are designed to deform as the filled plastic pots are pushed through to the bottom of the liner. This ensures a close fit around the plastic pot and the preset hole in the top tray limiting the amount of pebbles or bark that can fall into the black ABS liner.
- The ABS waterproof liner acts as saucer for the plants pots collecting excess water.
- If using pebbles, only place these in the top tray. Filling the liner around the plastic pots, up to the top of the planter will overload the planter and could effect the performance of the storage unit below.

4. Moving planters

- Remove pebbles/bark from top tray and plants before moving planter and liner. Once repositioned plants and pebbles/bark can be placed back into planter as before.



Perforated planter



Top tray sitting on ABS liner



Plain planter