# Agile - Electric 2 Column
## Assembly Instructions – Single Sided, Double Sided, Returns

**Tools Required:** Powered Screwdriver

## Contents

KNIGHT

**IMPORTANT!**

Please carefully read the assembly manual and direction for use prior to instalment, use and maintenance of the table frame to gain a complete understanding of its contents. It provides you with important information about the safety, use, installation and maintenance of the table.

**WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.**

**SAFETY**
- The table must be used in a safe manner. Inappropriate use may cause damage to the table and/or cause bodily harm to the user or persons nearby.
- Do not tamper with electrical components as this may lead to serious bodily harm.
- Only connect the electric table frames to the prescribed mains power voltage.
- Do not use the table frame to lift people.
- Please retain this operation manual and pass it on to any future owner.

**USAGE**
- The height-adjustable table is designed for use in dry work environments only.
- The table height is infinitely adjustable within its height range so that it can be set to the user's most ergonomic working height. The user should seek professional help to establish their optimum working height.
- The table has been designed as a devise to elevate the users work surface and associated office peripherals. Do not use the table frame for any other purposes than that which it has been designed for. Any other use is at user's own risk!
- Do not crawl, lie or move around under the table frame, and do not sit or stand on the table frame.
- CHILDREN should only use the table when supervised by adults.
- Liability: The manufacturer accepts under no circumstances warranty claims or liability claims for damages arising from improper use or handling of the table frame other than that described in this operation manual.

**SET UP AND INSTALLATION**

Assemble the table frame according to the following pages in this assembly instructions guide.

- Place the table in a safe distance from window frames, radiators, furniture etc. so that persons cannot become trapped.
- Level the table with the adjustable feet ensuring that the table is stable.
- Check that no cables can get jammed.
- Connect the table to the 110 or 230 VAC power outlet.

The table is now ready for use.

**MAINTENANCE**

- The table does not require any maintenance by the user
- The table is only to be cleaned with a wrung cloth.

**TECHNICAL DATA**

DESK
Height Range: 680-1130mm includes worktop
Speed: 22mm/s
Weight Rating: 120kg

WORKSTATION/DESK & RETURN
Height Range: 680-1130mm includes worktop
Speed: 22mm/s
Single Motor
Weight Rating: 100kg

Input Voltage: 100-240V AC 50-60Hz
Output Voltage: 24V DC 2.0A
Duty Cycle: 10% 2min on 18min off

## Parts



1 x L&R Leg Pair

2 x Foot

2 x Leg Rail Pair

1 x Cross Rail

1 x Drive Shaft

1 x L&R Support Bar Pair

1 x Power Cord

1 x Power Supply

1 x Handset

4 x Levelling Foot

8 x M8x25

8 x M8x10

6 x ST5.0x23

2 x ST3.9x2

# Agile - Electric 2 Column Single Sided Desk
**Assembly Instructions**

## Step 1

4 x M8x10

KNIGHT

# Agile - Electric 2 Column Single Sided Desk
**Assembly Instructions**

## Step 2

4 x M8x10

KNIGHT

# Agile - Electric 2 Column Single Sided Desk
**Assembly Instructions**

## Step 3



4 x Levelling Foot



8 x M8x25



**IMPORTANT!**
REFER TO PAGE 14 FOR
INSTALL OF SCREEN

**KNIGHT**

## Step 4



Length

| Worktop | Length |
|---------|--------|
| 1200mm | 1125mm |
| 1500mm | 1425mm |
| 1800mm | 1725mm |
| 2100mm | 2025mm |

**KNIGHT**

# Agile - Electric 2 Column Single Sided Desk
**Assembly Instructions**

## Step 5

1 x Drive Shaft

**KNIGHT**

# Agile - Electric 2 Column Single Sided Desk
**Assembly Instructions**

## Step 6

6 x ST5.0x23

**KNIGHT**

# Agile - Electric 2 Column Single Sided Desk
**Assembly Instructions**

## Step 7

2 x ST3.9x12

**KNIGHT**

## Step 8

## Completed

**KNIGHT**